



Brock's Performance • 4064 E. Patterson Road • Dayton, OH 45430 • Phone: 937-912-0054 • Fax: 937-912-0062

CARBON FIBER MIRROR BLOCK OFFS GSX-R600/750 (06-18) and GSX-R1000 (05-16) PRODUCT INFORMATION

Carbon Fiber Mirror Block Offs are designed to replace the OEM side view mirrors. Removal of the OEM side view mirrors reduces weight and aerodynamic drag. Carbon Fiber Mirror Block Offs are used to cover the holes and secure the front windscreen cowling.

Package Contents:

GSX-R1000 Mirror Block Offs shown:

1. One (1) Right Carbon Fiber Mirror Block Off
2. One (1) Left Carbon Fiber Mirror Block Off
3. Four (4) Black Aluminum Screws
4. One (1) Product Information Page

If your package contents differ, please contact Brock's Performance at 937-912-0054.



Installation Notes:

NOTE: This product is **NOT DOT** approved for street use.

1. Loosen four (4) nuts securing left and right side mirrors.
2. Remove six (6) bolts securing front windscreen.
3. Remove front windscreen.
4. Disconnect two connectors for the side mirror turn signals. (Fig 1)
5. Remove left and ride side mirrors.
6. Install windscreen and secure with six (6) bolts.
7. Install Carbon Fiber Mirror Block Offs using the supplied black aluminum screws and OEM nuts.
8. Torque black aluminum screws to 72 in-lb. (8 N·m).



ALL BROCK'S PERFORMANCE PRODUCTS ARE DESIGNED FOR CLOSED-COURSE RACETRACK USE ONLY!

For more information on Brock's Performance Warranty and Terms and Conditions:
BrocksPerformance.com > **Brock's Support** > **Customer Service** > **Terms and Conditions**

For Questions and Comments:
BrocksPerformance.com > **Brock's Support** > **Customer Service** > **Contact Us** or call 937-912-0054