

ZX-14/R (06-17) Steering Damper Kit (#930138)

Installation Instructions



Layout
(Figure 1)



Remove stock bolt
but leave spacer



Install steering stem
bracket assembly
(Figure 2)



Torque to:
(12N•m/106in•lb.)
(Figure 3)



Note up arrow on
clamp



Note dimple on
handlebar surface



Install master cylinder
bracket- reassemble at
dimple on top of the
stock clamp



Torque both screws
(8.8N•m/106in•lb.)
(Figure 4/5)



Torque 8MM to:
(17.2N•m/13 ft•lb.)
(Figure 6)



Torque 8MM to:
(17.2N•m/13 ft•lb.)
(Figure 7)



Adjust position
(@ 1.75 in./44.5mm)
Torque 5MM clamp bolts
(3.4N•m/30in•lb.)



**Inspect clearance
steering must be
unobstructed from
stop to stop!**

Figure #:

1. Öhlins road and track steering damper with clamp.
2. Brocks steering stem bracket kit (with factory installed bronze bushing)
3. M6x25 stainless steel socket head cap screw/flat washer (12N•m/106in•lb.)
4. Brocks master cylinder bracket.
5. M6x35 stainless steel socket head cap screws (2X) (8.8N•m/106in•lb.)
6. M8X25 stainless steel button head screw (17.2N•m/13 ft•lb.)
7. M8X30 stainless steel button head screw (17.2N•m/13 ft•lb.)