



[Brock's Performance](#) • 4064 E. Patterson Road • Dayton, OH 45430 • Phone: 937-912-0054 • Fax: 937-912-0062

CARBON FIBER MIRROR BLOCK OFFS NINJA H2 SX/SE/SE+ (18-21) PRODUCT INFORMATION

Carbon Fiber Mirror Block Offs are designed to replace the OEM side view mirrors. Removal of the OEM side view mirrors will reduce weight and aerodynamic drag. Carbon Fiber Mirror Block Offs are used to cover the holes and secure the front windscreen cowling.

Package Contents:

H2 SX/SE Mirror Block Offs shown:

1. One (1) Right Carbon Fiber Mirror Block Off
2. One (1) Left Carbon Fiber Mirror Block Off
3. Four (4) Black Aluminum Screws

If your package contents differ, please contact Brock's Performance at 937-912-0054.

For additional installation support please refer to the OEM service manual.



Installation Notes:

NOTE: This product is **NOT DOT** approved for street use.

1. Remove the upper inner fairings to access the turn signal connectors.
2. Disconnect the left and right side turn signal connectors.
3. Remove four (4) bolts securing left and right side mirrors.
4. Remove OEM left and right side mirrors.
5. Install Carbon Fiber Mirror Block Offs using the supplied black aluminum screws.
6. Torque black aluminum screws to 72 in-lb. (8 N·m).
7. Install the upper inner fairings.



ALL BROCK'S PERFORMANCE PRODUCTS ARE DESIGNED FOR CLOSED-COURSE RACETRACK USE ONLY!

For more information on Brock's Performance Warranty and Terms and Conditions:

[BrocksPerformance.com](#) > [Brock's Support](#) > [Customer Service](#) > [Terms and Conditions](#)

For Questions and Comments:

[BrocksPerformance.com](#) > [Brock's Support](#) > [Customer Service](#) > [Contact Us](#) or call 937-912-0054