



[Brock's Performance • 4064 E. Patterson Road • Dayton, OH 45430 • Phone: 937-912-0054 • Fax: 937-912-0062](#)

Brock's Performance H-D Touring Replacement Polyurethane Cush Drive Rubber Installation Information

NOTICE: IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN
Consult factory service manual for complete instructions & torque specifications for your machine

- Remove rear wheel, pulley carrier, and OEM cush drive isolator.
- Clean all parts thoroughly with brake cleaner or solvent and blow dry with compressed air.
- Insert 5 individual Brock's Performance Polyurethane Cush Drives into wheel as shown below.
- Use a rubber mallet, if necessary, for dry installation.
- Install pulley carrier into wheel - **pay special attention that the pulley carrier seats completely into the wheel.**
- Alternate wet installation: Lubrication, while making the carrier easier to install into the wheel, can also cause the carrier not to seat properly into the wheel (use the technique that works best for you and your application).
- Reinstall the rear wheel, spacers, etc... per service manual.

If you have any questions, please contact the Brock's Performance Technical line at (937) 912-0054 or email advice@brockperformance.com.



ALL BROCK'S PERFORMANCE PRODUCTS ARE DESIGNED FOR CLOSED-COURSE RACETRACK USE ONLY!

For more information on Brock's Performance Warranty and Terms and Conditions:

[BrocksPerformance.com](#) > [Brock's Support](#) > [Customer Service](#) > [Terms and Conditions](#)

For Questions and Comments:

[BrocksPerformance.com](#) > [Brock's Support](#) > [Customer Service](#) > [Contact Us](#) or call 937-912-0054