

EXTENDED REAR BRAKE CLEVIS LEVER KIT INSTALLATION INSTRUCTIONS

This kit is necessary when using an exhaust system that interferes with the rear brake lever. It raises the rear brake lever for clearance from the exhaust to allow for proper operation of the rear brake. This kit will fit most models with an M8-1.25 thread.

Check Package Contents:

The Package Contents Include:

1. One (1) Clevis Lock Pin
2. One (1) Clevis
3. One (1) Jam Nut

If your package contents differ, please contact Brock's Performance at 937-912-0054.

For additional installation support please refer to the OEM service manual.



Instructions:

1. Support the bike on a wheel stand or lift.
2. Remove OEM rear brake clevis and jam nut.
3. Drill out the rear brake lever arm with a letter "O" (.316 in) drill bit.

Note: On some models, it may be necessary to grind a small amount of material from the brake lever bracket. **Do NOT grind or remove any material from the brake lever arm as this could weaken the arm and cause failure.**

4. Install the Jam Nut to the master cylinder pushrod.
5. Install the supplied Clevis to the master cylinder pushrod.
6. Install the Clevis Lock Pin and rotate to lock into place.
7. Adjust rear brake pedal height until it no longer contacts the exhaust.
8. When the adjustment is complete tighten the Jam Nut to secure the Clevis.



ALL BROCK'S PERFORMANCE PRODUCTS ARE DESIGNED FOR CLOSED-COURSE RACETRACK USE ONLY!

For more information on Brock's Performance Warranty and Terms and Conditions:

BrocksPerformance.com > Brock's Support > Customer Service > Terms and Conditions

For Questions and Comments:

BrocksPerformance.com > Brock's Support > Customer Service > Contact us or call 937-912-0054