

H-D TOURING (02-13) LOWERING KIT KIT INSTALLATION INSTRUCTIONS

The three position lowering kit allows the bike to be lowered from 1" to 3" vs. stock height.

Check Package Contents:

The Package Contents Include:

1. Two (2) Brackets
2. Four (4) 2.25" Bolts
3. Two (2) 1.25" Bolts
4. Two (2) Washers
5. Two (2) Lock Washers
6. Two (2) Nyloc Nuts



If your package contents differ, please contact Brock's Performance at 937-912-0054.

For additional installation support please refer to the OEM service manual.

Instructions:

1. Support the bike using a wheel stand or lift.
2. If saddlebags are installed, remove at this time.
3. Remove the lower shock bolts from both sides of the bike.
4. Remove and replace the top shock bolts on both sides with the included 2.25" bolts (reuse the OEM spacers).

Note: DO NOT turn the shock upside down as this could let oil into the air passage and damage the shock.

5. Slide the supplied washer over the new bolt between the shock and the frame. Tighten the bolt hand tight.
6. Remove the belt tensioner nuts from the rear of the swingarm (**DO NOT** loosen the axle nut).
7. Using the supplied 1.25" bolts and lock washers, install the brackets to the original lower shock mounting points. Tighten everything up.
8. Select the desired ride height (After making any adjustments to ride height, assure there is enough ground clearance that the bike does not bottom out).
9. Install the supplied bolt and Nyloc nut hand tight (the nut goes towards the wheel).
10. Lower the bike down to where the full bike weight is on the rear tire. Then tighten everything to OEM torque specs.

ALL BROCK'S PERFORMANCE PRODUCTS ARE DESIGNED FOR CLOSED-COURSE RACETRACK USE ONLY!

For more information on Brock's Performance Warranty and Terms and Conditions:

[BrocksPerformance.com](#) > [Brock's Support](#) > [Customer Service](#) > [Terms and Conditions](#)

For Questions and Comments:

[BrocksPerformance.com](#) > [Brock's Support](#) > [Customer Service](#) > [Contact us](#) or call 937-912-0054